

Free Running Gross Alarm Setpoint Example

ProAction PCEE - [Free Running Gross Alarm Setpoint]

File Communications Tools View Help

Step List

Step #	Name
1	Free Running Gross SP

New Step
Rename Step
Remove Step
Move Step Up
Move Step Down

☒ Enabled ☐ Pausable

Conditions "True" Actions "False" Actions Pause Actions

Conditions

◆ Weight Compare

Free Running Gross Alarm Setpoint

STEP 1: Free Running Gross SP (Enabled, Not Pausable)

CONDITIONS

Weight Compare, Source: SCALE1, Value: 1000, Mode: GROSS, Trip: HIGHER, Band Value: 0,
Preact Mode: OFF, Preact Value: 0
Comment: Gross Setpoint Tripping above 1000

TRUE ACTIONS

Digital Output, Slot: 0, Relay Number: 1, State: ON
Comment: Turn on the 1st Digital Output above 1000

FALSE ACTIONS

Digital Output, Slot: 0, Relay Number: 1, State: OFF
Comment: Turn off the 1st Digital Output below 1000

PAUSE ACTIONS